


AB Fellingsbro
Verkstäder

M68-RA 46F



Grundinställning
Ordinary presetting
Grundeinstellung
Préréglage normal

20%

30


40

50

60

80

70



40%
40%
40%
40%